

Treated Pine

ezistep

DIY saves time & money!

**MADE IN
AUSTRALIA**

**For Domestic
Use Only**



CODE	No. STEPS	TOTAL HEIGHT
STEP1	1	320mm
STEP2	2	480mm
STEP3	3	640mm
STEP4	4	800mm
STEP5	5	960mm

The ezistep can be assembled with a power drill with a square head to fit screw size 10g x 63.5mm / (screws supplied)
The treads can be easily assembled as the stringers are routed in for secure and longer lasting construction

THIS KIT CONTAINS:

- 2 side timbers (stringers)
- Stainless decking screws
- Tread timber - (900mm x 45mm x 250mm)

TO ASSEMBLE YOU WILL NEED

- Power drill
- No. 2 Square Drive Bit