

Treated Pine

ezistep

DIY saves time & money!

**MADE IN
AUSTRALIA**

**For Domestic
Use Only**



| CODE | No. STEPS | TOTAL HEIGHT |
|-------|-----------|--------------|
| STEP1 | 1 | 320mm |
| STEP2 | 2 | 480mm |
| STEP3 | 3 | 640mm |
| STEP4 | 4 | 800mm |
| STEP5 | 5 | 960mm |

The ezistep can be assembled with a power drill with a square head to fit screw size 10g x 63.5mm / (screws supplied)
The treads can be easily assembled as the stringers are routed in for secure and longer lasting construction

THIS KIT CONTAINS:

- 2 side timbers (stringers)
- Stainless decking screws
- Tread timber - (900mm x 45mm x 250mm)

TO ASSEMBLE YOU WILL NEED

- Power drill
- No. 2 Square Drive Bit